


## UNPACKING AND REMOVING THE UNIT FROM THE PALLET



Removable parts of packaging



**Perform this action safely with two people for larger types**

Remove the crate from the unit by taking of the following parts:

- wooden top plate and protection
- vertical beams and protection
- slide unit down from plank-bridge base construction

Follow the instructions as given.

After the unit is unpacked, you can apply the accessories as shown in the pictures on the separate instruction sheet.



### WARNING

Read the instructions before using the machine.

1



Remove side beams 2x

2



Remove top plate

3




Remove protection top

4




Remove vertical beams and protection on front side

5



Remove vertical beams and protection on backside

6




Remove outer screw 4x2  
Leave middle screw in place



**WARNING**

Prevent the unit from rolling away on the casters.

7



Small side of beam


Place vertical beam under cabinet  
On both sides

10



Tilt cabinet slightly  
Place under front wheels of cabinet

8



Front view  
1 beam left + 1 beam right

11



Carefully slide unit onto floor

9



Flatten 2 remaining beams

12



Remove remaining screws

13



Remove metal brackets 4x

14




Remove protection foil

15



Remove screws (3x)

16



a) Remove safety beam front and shelves  
b) Remove protection foil of the shelves