

## Instruction for cross selling top

1)

**Warning !**

**Disconnect the power before  
changing the top**

2) remove the 2 caps




3) remove the screws



4) remove the top



5) place the new cross selling top



6) replace the screws



7) replace the new caps

