



Connect instructions pedal switch TDR Ac 9124490

	A ₂ 1 (-)	94 A ₂ 5 (+)		A.B. K3*		3 (14) 96	2 (12)	4 (11) 97
	(7)			10.AMP □ F1			(30)	
	(13)			10.AMP □ F2			(57)	
	O BK P1 O 80*	1	-24volt			90 O 79 O		
	O 82 O	2	-24vol1			O 71 O		
	O RD P1	3				O 76 O		
	O C2 O	4				O 56 O		
	O C1 O M1/WH	5				22/BU* O 34 O		
	O C1 O M1/WH/A	6				O O O		
	O 39 O 23/BR*	7				45 O 31 O		
	O 30 O 97*	8				33 O 38 O		
	O 1 O 7	9				O 10 O		
	O 2 O 99*	10				8 O 12 O		
	O 3 O	11				9 O 11 O		
	O 63 O C2	12				98* O O		
	O 59 O M1/BN	13				61 O 69 O		
	O O 52	14				32 O 57 O		
	O 13 O 4	15				O 16 O		
	O 92 O 5	16				14 O 17 O		
	O 6 O	17				15 O 18 O		
	O PE O PE					PE O PE O		
	O O					PE O O		

Place the wire of the pedal switch on Cb5 and Cb7



Place stain relief. When hole missing drill the hole (25mm.) on de same place as picture.