

## Air guide kit, lamps TDRac 9314060s

### Contents kit.



9314058 2x Air guide

0144347 4x Nut M4 self locking

0141117 4x Screw M4x 45 (spare)

9311059 2 mtr sealing tape

2x



Disconnect mains power !

1 Remove both side panels and the top panels.

2 Unscrews the 2 upper screws from both cooling fans.

3 Mount the both air guides as shown with 2 screws each

4 Fix the top side of the fans with the delivered M4 nuts.

5 Place the self sticking sealing tape on the indicated position.

Put back the panels.

