


UPDATING SOFTWARE TDRAC (S-CONTROL)


Preparing the software (firmware)

The software comes in a .zip file. The name corresponds with the version of the software. For example: *V1_00_3.zip*.

1. Extract the zip file




2. Copy or move the folder "42-S_CPU.1" to the USB drive.



Updating the software (firmware)


1. Disconnect the mains supply



2. Connect the USB drive.



3. Connect the mains supply



4. The following messages appear

Bootloader version V4.03.04

-USB stick found
starting upgrade

-Copying update.tar

-in progress .. %

-USB can be removed

-Removing current application

-Extracting archive .. %

-Please remove USB stick

5. Disconnect the USB drive and wait until the screen comes back.



Important first setting !!

In the service menu, the parameter "commision apply" needs to be set on "yes".

Otherwise, cooking programs will be lost after a power disconnection.

In case a new board has just been put into a unit, it has to be set to the right device type! -> TDRac